
Battery replacement:



Light bulb

Max power consumption	≤5W		
Luminous flux	300Lm/360Lm	Working voltage	DC 5V-1200mA
Color temperature	Cold light 6500K/360Lm Warm light 3000K/300Lm Cold light and Warm light 4000K	Max Power	5W

Care and Cleaning

EXTERIOR MAINTENANCE

- To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
- 2. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.



INSTRUCTIONS MANUAL

for Hubert

LED INTERIOR TABLE LAMP

Art Nr. 40257-001-53



Main Function:

- Available 3 mode (Cold light Warm light Natural light), excellent color reality and eye-protection.
- Adopt high performance LED light and components, lighting more concentrate.
- High sensitivity touch panel, elegant control experience.
- 3 Grade brightness strengths, applicable to different lighting requirements.
- Folding and biaxial rotary design, easy to get best lighting angle.
- Low energy consumption design, saving 80% than incandescent lamp.
- Does not contain the Tungsten, Mercury and other toxic metal, environmental friendly.
- No fragile glass parts, safe and ease.
- Digital tube display with Calendar and alarm clock.

Pre-Installation

PLANNING THE INSTALLATION


Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

TOOLS REQUIRED




User guide

Connect the power adapter in the rear of the lamp holder.




Touch to turn on the power supply (please refer to Operation instructions):




When adjusting the lamp arm, please hold the base.
Arm adjustable range: 180° (excessive adjustment may cause damage)



Chimney angle adjustable, to meet your lighting demands. Adjustable range: 75° of each side (excessive adjustment may cause damage)



Lighting area: Adjustable angle of the lamp stand: 90° When adjusting the lamp arm,



Light Operation instruction

■ Touch key instructions:



- Turn on/off the lamp: touch "ON/OFF"
- Brightness adjusting: touch "UP" or "DOWN"
- Lighting mode: Cold light Warm light Natural light, Switchable

Calendar Operation instruction



■ S (setting)

Press " S " for around 3 second, the " MONTH " will flicker, then click " \land " and " \lor " to adjust " MONTH ", after " MONTH " setting, click " S " key again to set the " DATE ", " HOUR ", " MINUTE ".

After " MINUTE " setting, click " S " again, " 24H " will flicker , then " \land " and " \lor " to select " 12 " or " 24H ".

Then click " S " again to active alarm clock, and click " Λ " and " \vee " to set alarm time.

In setting mode, clieck it to increase

■ ∨ (down key)

In setting mode, clieck it to decrease.

* In normal time mode, click it to turn on/off the alarm clock.

