
Package contents (parts are not to scale):



Part	Description	Quantity
Α	Fixture body with wire	1
В	Wall expansion particle	2
С	Self-Tapping screw	2

Light source

LED SMD 22W 1650Lumen 3000K (Dimmable)

Care and Cleaning

EXTERIOR MAINTENANCE

- 1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
- 2. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.




INSTRUCTIONS MANUAL

for MANHATTEN

INTERIOR PENDANT

Art Nr. 53977-022-71



www.lampehuset.no

Pre-Installation

PLANNING THE INSTALLATION


Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

TOOLS REQUIRED




Installation (Make sure to turn off the main power)


Step 1.




Step 2.




Step 3.



Step 4. Adjust lamp height



Installation (continued)



Operation

- ☐ Turn on power at the circuit breaker or fuse box.
- ☐ Turn the light switch on to activate the fixture.