


ART NR. 50424-000-71, 50424-000-53

Three-wires Fiexible Connector



Loosen the 2 screws B on the three-wire fiexible connector first, then insert the three-wire tracks into the connector in the direction of the arrow, and finally tighten the screws B