


Package contents (parts are not to scale):

A



Part	Description	Quantity
A	The fixture with wire	1

Light source

Main Light: LED 22W 2000lm 3000K

Side Light: LED 6W 550lm 3000K

(LED driver plug warranty: 3 years)

Dimmer

With dimmer on the lamp

Care and Cleaning

EXTERIOR MAINTENANCE

1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
2. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.


STONE FIELD
by S.A.E

INSTRUCTIONS MANUAL

for HELIOS

INTERIOR FLOOR LAMP

Art Nr. 34078-000-71, 34078-000-03
34078-000-00, 34078-000-01



Pre-Installation

PLANNING THE INSTALLATION


Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

TOOLS REQUIRED




Knife

Installation



2

Installation (continued)



Operation

- Turn on power at the circuit breaker or fuse box.
- Turn the light switch on to activate the fixture.

3