

BT22204 COOL SPEAKER LAMP

LED Bluetooth speaker wireless charging



IINSTRUCTION MANUAL

**Start by charging the Speaker lamp by using the included USB cable, until its fully charged.
Please note that the Usb cable must be connected for wireless charging of the cell phone !**



Long press to start/short press to switch lights/Double-click to turn off the light



Bluetooth/FM/USB/TF/AUX mode



Long press to decrease the volume, short press once



Play/Pause



Long press to increase the volume, short press the previous song

Technical Parameter

Wireless charging power:10W

Bluetooth version: 5.2

Bluetooth pairing name: BT22204

Output power: 5W

Bluetooth frequency:2.4GHZ-2.48GHZ

Transmission distance: 10m

Frequency response range:50HZ-20KHZ

Signal to noise ratio of the whole machine:> 75db

Built-in Lithium battery voltage: 3.7V

Charging input: DC 5V/500MA.

Charging time/playing time 2-3 hours/3-6 hours (depending on the feature use and volume)

Product size and weight :235*80*238 mm: 770g

Key function operation instructions:

I Power on: press and hold the power on button for two seconds to start the machine, and the default warm light is on

II Bluetooth function use:

1. This audio system supports the use of Bluetooth devices with A2DP function. First, Turn it on, and press and hold the M key to enter. When the Bluetooth mode is entered, the blue light of the Bluetooth indicator light flashes, accompanied by voice prompt, and the audio. It is in the state of waiting for pairing connection. Only in this state can it be connected with Bluetooth audio pair and connect.

2. Mobile phone connection

Step 1: Open the Bluetooth setting switch in the mobile phone settings, and click Search Device

Step 2: When the BT22204 character is displayed on the available device, it means that the mobile phone has found the Bluetooth audio, click BT22204 enters the pairing mode. After the phone and audio are successfully paired, a voice prompt will be displayed Show connected

III TWS antithesis function (this function is only applicable to Bluetooth mode)

When you have two BT22204 Bluetooth stereos, long press one of them to pair, and Bluetooth is connected to each other, the two stereos will automatically changed into left and right channels to produce stereo surround sound effect, realizing true wireless stereo.

Light Use

1) BT22204 Bluetooth speaker is equipped with a variety of lighting effects

2) The default light warming effect is when the device is turned on. press the light key to adjust the light.

FM Radio Use:

Short press the M key to switch to the FM function, and connect the AUX cable to the product AUX interface to act as radio receiver. The other end of the line does not need to be connected with any equipment. Press the pause key to enter the automatic radio search Search and save automatically, and the radio station searched will select the saved radio station through "+/-" .

Aux Cable included.

TF Card/U disk Function Use:

Insert the TF card/U disk into the card slot, the corresponding voice prompt will appear, and the product will automatically read The audio file in the card is played, and the user can use the speaker "+/-" button to control the size of the music sound.

Safety Instructions:

1. Don't expose the product into the water or humid areas, such as bathrooms. The product is for indoor use only. IP20.
2. Please do not hit or drop the product hardly to avoid manual damage.
3. When not in use for a long time, please turn off the power.

BT22204 COOL SPEAKER LAMP

Bluetooth højttaler lampe, med trådløs mobil opladning



INSTRUKTIONS MANUAL

Start med at lade den op via det medfølgende Usb stik, indtil den er fuldt opladet. Bemærk at Usb stikket skal være tilsluttet ved trådløs opladning af mobiltelefonen



Langt tryk for at starte/kort tryk for at skifte lys/Dobbelklik for at slukke lyset



Bluetooth/FM/USB/TF/AUX-tilstand



Langt tryk for at mindske lydstyrken, kort tryk én gang



Afspil/pause



Langt tryk for at øge lydstyrken, tryk kort på den forrige sang

Teknisk parametre.

Trådløs opladningseffekt: 10W

Bluetooth version: 5.2

Bluetooth pare navn: BT22204

Udgangseffekt: 5W

Bluetooth-frekvens: 2.4GHZ-2.48GHZ

Transmissionsafstand: 10m

Frekvensresponsområde: 50HZ-20KHZ

Signal til støjforhold for hele maskinen: ~75db

Indbygget litium batteri: 3,7V

Lade input: DC 5V/500MA

Opladning/afspilnings tid: 2-3 timer/3-6 timer (afhængig af brug af funktioner og volumen)

Produkt størrelse og vægt::235*80*238 mm: 770g

Nøglefunktions betjeningsinstruktioner:

I . Tænd: tryk og hold tænd/sluk-knappen nede i to sekunder for at starte maskinen, og det varme standardlys er tændt

II .Brug af Bluetooth-funktion:

1. Dette lydsystem understøtter brugen af Bluetooth-enheder med A2DP-funktion. Tænd først den, og tryk og hold M-tasten nede for at komme ind. Når Bluetooth-tilstanden aktiveres, blinker det blå lys på Bluetooth-indikatorlyset, ledsaget af en stemmemeddelelse og lyden. Den er i en tilstand, hvor den venter på parringsforbindelse. Kun i denne tilstand kan den forbindes med Bluetooth-lydpar og forbindes.

2 Mobil telefon forbindelse

Trin 1: Åbn Bluetooth-indstillingsknappen i mobiltelefonindstillingerne, og klik på Søg enhed

Trin 2: Når BT22204 -tegnet vises på den tilgængelige enhed, betyder det, at mobiltelefonen har fundet Bluetooth-lyden, klik på BT22204 for at gå ind i parringstilstand. Når telefonen og lyden er blevet parret, vises en stemmemeddelelse Vis tilsluttet.

III . TWS antitese-funktion (denne funktion er kun anvendelig til Bluetooth-tilstand)

Når du har to BT22204: For Bluetooth-stereoanlæg, skal du trykke længe på den ene af dem for at parre, og Bluetooth er forbundet med hinanden, vil de to stereoanlæg automatisk ændres til venstre og højre kanal for at producere stereo -lydeffekt, der realiserer trådløs stereo.

Brug af Led lys

1) BT22204 Bluetooth-højttaler er udstyret med en lang række lyseffekter

2) Standard lysopvarmningseffekter, når enheden tændes. Tryk på lystasten for at justere lyset.

Brug af FM-radio:

Tryk kort på M-tasten for at skifte til FM-funktionen, og tilslut AUX-kablet til produktets AUX-interface for at fungere som radiomodtager. Den anden ende af linjen behøver ikke at være forbundet med noget udstyr. Tryk på pausetasten for at gå ind i den automatiske radiosøgning Søg og gem automatisk, og den søgte radiostation vil vælge den gemte radiostation med "+/-" .

Aux kablet er inkluderet

TF Card/U disk Funktionsbrug:

Indsæt TF-kortet/U-disken i kortåbningen, den tilsvarende stemmemeddelelse vises, og produktet vil automatisk læse. Lydfilen på kortet afspilles, og brugeren kan bruge højttaler-"+/-"-knappen til at styre størrelsen på musiklyden.

SIKKERHEDS INSTRUKTION

1. Udsæt ikke produktet for høj varme, vand eller fugtige områder, såsom badeværelser.

Produktet er Kun godkendt til indendørs brug IP20.

2. Sluk for strømmen, når den ikke er i brug i længere tid

VELI LINE ApS, Gefionsvej 4, DK 3400 Hillerød